

西门子按钮

型号	类型	颜色	常用触点数量	单价
3SB6160-0AB20-1CA0	平头按钮 模块化, 瞬动	红	1NC	32.9
3SB6160-0AB40-1BA0	平头按钮 模块化, 瞬动	绿	1NO	32.9
3SB6160-0AB50-1BA0	平头按钮 模块化, 瞬动	蓝	1NO	32.9
3SB6160-0AB30-1BA0	平头按钮 模块化, 瞬动	黄	1NO	32.9
3SB6160-0AB60-1BA0	平头按钮 模块化, 瞬动	白	1NO	32.9
3SB6160-0AB10-1BA0	平头按钮 模块化, 瞬动	黑	1NO	32.9
3SB6160-0AB10-1CA0	平头按钮 模块化, 瞬动	黑	1NC	32.9
3SB6160-0BB20-1CA0	凸头按钮 瞬动	红	1NC	49.8
3SB6160-0BB40-1BA0	凸头按钮 瞬动	绿	1NO	49.8
3SB6160-0BB50-1BA0	凸头按钮 瞬动	蓝	1NO	49.8
3SB6160-0BB30-1BA0	凸头按钮 瞬动	黄	1NO	49.8
3SB6160-0BB60-1BA0	凸头按钮 瞬动	白	1NO	49.8
3SB6160-0BB10-1BA0	凸头按钮 瞬动	黑	1NO	49.8
3SB6160-0BB10-1CA0	凸头按钮 瞬动	黑	1NC	49.8
3SB6163-0DB20-1CA0	带灯平头按钮 24V AC/DC	红	1NC	53.8
3SB6163-0DB40-1BA0	带灯平头按钮 24V AC/DC	绿	1NO	53.8
3SB6163-0DB50-1BA0	带灯平头按钮 24V AC/DC	蓝	1NO	53.8
3SB6163-0DB30-1BA0	带灯平头按钮 24V AC/DC	黄	1NO	53.8
3SB6163-0DB60-1BA0	带灯平头按钮 24V AC/DC	白	1NO	53.8
3SB6165-0DB20-1CA0	带灯平头按钮 110V AC/DC	红	1NC	53.8
3SB6165-0DB40-1BA0	带灯平头按钮 110V AC/DC	绿	1NO	53.8
3SB6165-0DB50-1BA0	带灯平头按钮 110V AC/DC	蓝	1NO	53.8
3SB6165-0DB30-1BA0	带灯平头按钮 110V AC/DC	黄	1NO	53.8
3SB6165-0DB60-1BA0	带灯平头按钮 110V AC/DC	白	1NO	53.8
3SB6166-0DB20-1CA0	带灯平头按钮 220V AC	红	1NC	53.8
3SB6166-0DB40-1BA0	带灯平头按钮 220V AC	绿	1NO	53.8
3SB6166-0DB50-1BA0	带灯平头按钮 220V AC	蓝	1NO	53.8
3SB6166-0DB30-1BA0	带灯平头按钮 220V AC	黄	1NO	53.8
3SB6166-0DB60-1BA0	带灯平头按钮 220V AC	白	1NO	53.8
3SB6160-2AA10-1BA0	旋钮 (短柄) 2位, L-R, 90	黑	1NO	40
3SB6160-2AL10-1NA0	旋钮 (短柄) 3位, L-C-R, 2×60	黑	2×1NO	53.5
3SB6160-2AM10-1NA0	旋钮 (短柄) 3位, L>C<R, 2×60	黑	2×1NO	64.6
3SB6160-2AN10-1NA0	旋钮 (短柄) 3位, L-C<R, 2×60	黑	2×1NO	64.6
3SB6160-2AP10-1NA0	旋钮 (短柄) 3位, L>C-R, 2×60	黑	2×1NO	64.6
3SB6160-2BA10-1BA0	旋钮 (长柄) 2位, L-R, 90	黑	1NO	44.3
3SB6160-2BL10-1NA0	旋钮 (长柄) 3位, L-C-R, 2×60	黑	2×1NO	57.8
3SB6160-2BM10-1NA0	旋钮 (长柄) 3位, L>C<R, 2×60	黑	2×1NO	69
3SB6160-2BN10-1NA0	旋钮 (长柄) 3位, L-C<R, 2×60	黑	2×1NO	69
3SB6160-2BP10-1NA0	旋钮 (长柄) 3位, L>C-R, 2×60	黑	2×1NO	69
3SB6160-4AA01-1BA0	钥匙开关 2位, KL-R, 90	黑	1NO	52.5
3SB6160-4AA21-1BA0	钥匙开关 2位, L-KR, 90	黑	1NO	52.5
3SB6160-4AA11-1BA0	钥匙开关 2位, KL-KR, 90	黑	1NO	52.5
3SB6160-4AL01-1NA0	钥匙开关 3位, L-KC-R, 2×60	黑	2×1NO	62.9
3SB6160-4AL11-1NA0	钥匙开关 3位, KL-KC-KR, 2×60	黑	2×1NO	62.9
3SB6160-4AM01-1NA0	钥匙开关 3位, L>KC<R, 2×60	黑	2×1NO	74.5

3SB6160-1AC20-1CA0	蘑菇头按钮	30mm, 瞬动	红		1NC	46.5
3SB6160-1BC20-1CA0	蘑菇头按钮	40mm, 瞬动	红		1NC	46.5
3SB6160-1BA20-1CA0	蘑菇头按钮	40mm, 上拉解锁	红		1NC	48.1
3SB6160-1CC20-1CA0	蘑菇头按钮	60mm, 瞬动	红		1NC	46.5
3SB6160-1HB20-1CA0	急停按钮	40mm, 旋转解锁	红		1NC	52.3
3SB6160-1HA20-1CA0	急停按钮	40mm, 上拉解锁	红		1NC	48.8
3SB6160-1HD20-1CA0	急停按钮	40mm, 钥匙解锁	红		1NC	69.6
3SB6211-6AA20-1AA0	指示灯	6V AC/DC	红			21
3SB6211-6AA30-1AA0	指示灯	6V AC/DC	黄			21
3SB6211-6AA40-1AA0	指示灯	6V AC/DC	绿			21
3SB6211-6AA50-1AA0	指示灯	6V AC/DC	蓝			21
3SB6211-6AA60-1AA0	指示灯	6V AC/DC	白			21
3SB6212-6AA20-1AA0	指示灯	12V AC/DC	红			21
3SB6212-6AA30-1AA0	指示灯	12V AC/DC	黄			21
3SB6212-6AA40-1AA0	指示灯	12V AC/DC	绿			21
3SB6212-6AA50-1AA0	指示灯	12V AC/DC	蓝			21
3SB6212-6AA60-1AA0	指示灯	12V AC/DC	白			21
3SB6213-6AA20-1AA0	指示灯	24V AC/DC	红			21
3SB6213-6AA30-1AA0	指示灯	24V AC/DC	黄			21
3SB6213-6AA40-1AA0	指示灯	24V AC/DC	绿			21
3SB6213-6AA50-1AA0	指示灯	24V AC/DC	蓝			21
3SB6213-6AA60-1AA0	指示灯	24V AC/DC	白			21
3SB6214-6AA20-1AA0	指示灯	48V AC/DC	红			21
3SB6214-6AA30-1AA0	指示灯	48V AC/DC	黄			21
3SB6214-6AA40-1AA0	指示灯	48V AC/DC	绿			21
3SB6214-6AA50-1AA0	指示灯	48V AC/DC	蓝			21
3SB6214-6AA60-1AA0	指示灯	48V AC/DC	白			21
3SB6215-6AA20-1AA0	指示灯	110V AC/DC	红			21
3SB6215-6AA30-1AA0	指示灯	110V AC/DC	黄			21
3SB6215-6AA40-1AA0	指示灯	110V AC/DC	绿			21
3SB6215-6AA50-1AA0	指示灯	110V AC/DC	蓝			21
3SB6215-6AA60-1AA0	指示灯	110V AC/DC	白			21
3SB6216-6AA20-1AA0	指示灯	220V AC	红			21
3SB6216-6AA30-1AA0	指示灯	220V AC	黄			21
3SB6216-6AA40-1AA0	指示灯	220V AC	绿			21
3SB6216-6AA50-1AA0	指示灯	220V AC	蓝			21
3SB6216-6AA60-1AA0	指示灯	220V AC	白			21
3SB6217-6AA20-1AA0	指示灯	220V AC	红			21
3SB6217-6AA30-1AA0	指示灯	220V AC	黄			21
3SB6217-6AA40-1AA0	指示灯	220V AC	绿			21
3SB6217-6AA50-1AA0	指示灯	220V AC	蓝			21
3SB6217-6AA60-1AA0	指示灯	220V AC	白			21
3SB6218-6AA20-1AA0	指示灯	380V AC	红			22.7
3SB6218-6AA30-1AA0	指示灯	380V AC	黄			22.7
3SB6218-6AA40-1AA0	指示灯	380V AC	绿			22.7
3SB6218-6AA50-1AA0	指示灯	380V AC	蓝			22.7
3SB6218-6AA60-1AA0	指示灯	380V AC	白			22.7

3SB6060-0AB10-0YAO	平头按钮头	瞬动	黑		21.5
3SB6060-0AB20-0YAO	平头按钮头	瞬动	红		21.5
3SB6060-0AB30-0YAO	平头按钮头	瞬动	黄		21.5
3SB6060-0AB40-0YAO	平头按钮头	瞬动	绿		21.5
3SB6060-0AB50-0YAO	平头按钮头	瞬动	蓝		21.5
3SB6060-0AB60-0YAO	平头按钮头	瞬动	白		21.5
3SB6060-0BB10-0YAO	凸头按钮头	瞬动	黑		38.4
3SB6060-0BB20-0YAO	凸头按钮头	瞬动	红		38.4
3SB6060-0BB30-0YAO	凸头按钮头	瞬动	黄		38.4
3SB6060-0BB40-0YAO	凸头按钮头	瞬动	绿		38.4
3SB6060-0BB50-0YAO	凸头按钮头	瞬动	蓝		38.4
3SB6060-0BB60-0YAO	凸头按钮头	瞬动	白		38.4
3SB6061-0AB20-0YAO	带灯按钮头	瞬动	红		26.2
3SB6061-0AB30-0YAO	带灯按钮头	瞬动	黄		26.2
3SB6061-0AB40-0YAO	带灯按钮头	瞬动	绿		26.2
3SB6061-0AB50-0YAO	带灯按钮头	瞬动	蓝		26.2
3SB6061-0AB60-0YAO	带灯按钮头	瞬动	白		26.2
3SB6061-0BB20-0YAO	带灯凸头按钮头	瞬动	红		46.6
3SB6061-0BB30-0YAO	带灯凸头按钮头	瞬动	黄		46.6
3SB6061-0BB40-0YAO	带灯凸头按钮头	瞬动	绿		46.6
3SB6061-0BB50-0YAO	带灯凸头按钮头	瞬动	蓝		46.6
3SB6061-0BB60-0YAO	带灯凸头按钮头	瞬动	白		46.6
3SB6060-2AA10-0YAO	旋钮（短柄）头	2位, L-R, 90	黑		28.6
3SB6060-2AA20-0YAO	旋钮（短柄）头	2位, L-R, 90	红		28.6
3SB6060-2AA30-0YAO	旋钮（短柄）头	2位, L-R, 90	黄		28.6
3SB6060-2AA40-0YAO	旋钮（短柄）头	2位, L-R, 90	绿		28.6
3SB6060-2AA50-0YAO	旋钮（短柄）头	2位, L-R, 90	蓝		28.6
3SB6060-2AA60-0YAO	旋钮（短柄）头	2位, L-R, 90	白		28.6
3SB6060-2AB10-0YAO	旋钮（短柄）头	2位, L<R, 90	黑		39.6
3SB6060-2AB20-0YAO	旋钮（短柄）头	2位, L<R, 90	红		39.6
3SB6060-2AB30-0YAO	旋钮（短柄）头	2位, L<R, 90	黄		39.6
3SB6060-2AB40-0YAO	旋钮（短柄）头	2位, L<R, 90	绿		39.6
3SB6060-2AB50-0YAO	旋钮（短柄）头	2位, L<R, 90	蓝		39.6
3SB6060-2AB60-0YAO	旋钮（短柄）头	2位, L<R, 90	白		39.6
3SB6060-2AL10-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	黑		31.7
3SB6060-2AL20-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	红		31.7
3SB6060-2AL30-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	黄		31.7
3SB6060-2AL40-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	绿		31.7
3SB6060-2AL50-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	蓝		31.7
3SB6060-2AL60-0YAO	旋钮（短柄）头	3位, L-C-R, 2×60	白		31.7
3SB6060-2AM10-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	黑		42.9
3SB6060-2AM20-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	红		42.9
3SB6060-2AM30-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	黄		42.9
3SB6060-2AM40-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	绿		42.9
3SB6060-2AM50-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	蓝		42.9
3SB6060-2AM60-0YAO	旋钮（短柄）头	3位, L>C<R, 2×60	白		42.9
3SB6060-2AN10-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	黑		42.9

3SB6060-2AN20-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	红			42.9
3SB6060-2AN30-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	黄			42.9
3SB6060-2AN40-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	绿			42.9
3SB6060-2AN50-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	蓝			42.9
3SB6060-2AN60-0YAO	旋钮（短柄）头	3位, L-C<R, 2×60	白			42.9
3SB6060-2AP10-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	黑			42.9
3SB6060-2AP20-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	红			42.9
3SB6060-2AP30-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	黄			42.9
3SB6060-2AP40-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	绿			42.9
3SB6060-2AP50-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	蓝			42.9
3SB6060-2AP60-0YAO	旋钮（短柄）头	3位, L>C-R, 2×60	白			42.9
3SB6060-2BA10-0YAO	旋钮（短柄）头	2位, L-R, 90	黑			33
3SB6060-2BA20-0YAO	旋钮（长柄）头	2位, L-R, 90	红			33
3SB6060-2BA30-0YAO	旋钮（长柄）头	2位, L-R, 90	黄			33
3SB6060-2BA40-0YAO	旋钮（长柄）头	2位, L-R, 90	绿			33
3SB6060-2BA50-0YAO	旋钮（长柄）头	2位, L-R, 90	蓝			33
3SB6060-2BA60-0YAO	旋钮（长柄）头	2位, L-R, 90	白			33
3SB6060-2BB10-0YAO	旋钮（长柄）头	2位, L<R, 90	黑			43.9
3SB6060-2BB20-0YAO	旋钮（长柄）头	2位, L<R, 90	红			43.9
3SB6060-2BB30-0YAO	旋钮（长柄）头	2位, L<R, 90	黄			43.9
3SB6060-2BB40-0YAO	旋钮（长柄）头	2位, L<R, 90	绿			43.9
3SB6060-2BB50-0YAO	旋钮（长柄）头	2位, L<R, 90	蓝			43.9
3SB6060-2BB60-0YAO	旋钮（长柄）头	2位, L<R, 90	白			43.9
3SB6060-2BL10-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	黑			36.1
3SB6060-2BL20-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	红			36.1
3SB6060-2BL30-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	黄			36.1
3SB6060-2BL40-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	绿			36.1
3SB6060-2BL50-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	蓝			36.1
3SB6060-2BL60-0YAO	旋钮（长柄）头	3位, L-C-R, 2×60	白			36.1
3SB6060-2BM10-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	黑			47.2
3SB6060-2BM20-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	红			47.2
3SB6060-2BM30-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	黄			47.2
3SB6060-2BM40-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	绿			47.2
3SB6060-2BM50-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	蓝			47.2
3SB6060-2BM60-0YAO	旋钮（长柄）头	3位, L>C<R, 2×60	白			47.2
3SB6060-2BN10-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	黑			47.2
3SB6060-2BN20-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	红			47.2
3SB6060-2BN30-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	黄			47.2
3SB6060-2BN40-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	绿			47.2
3SB6060-2BN50-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	蓝			47.2
3SB6060-2BN60-0YAO	旋钮（长柄）头	3位, L-C<R, 2×60	白			47.2
3SB6060-2BP10-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	黑			47.2
3SB6060-2BP20-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	红			47.2
3SB6060-2BP30-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	黄			47.2
3SB6060-2BP40-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	绿			47.2
3SB6060-2BP50-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	蓝			47.2
3SB6060-2BP60-0YAO	旋钮（长柄）头	3位, L>C-R, 2×60	白			47.2

3SB6061-2AA20-0YAO	带灯旋钮（短柄）头	2位, L-R, 90	红			37.2
3SB6061-2AA30-0YAO	带灯旋钮（短柄）头	2位, L-R, 90	黄			37.2
3SB6061-2AA40-0YAO	带灯旋钮（短柄）头	2位, L-R, 90	绿			37.2
3SB6061-2AA50-0YAO	带灯旋钮（短柄）头	2位, L-R, 90	蓝			37.2
3SB6061-2AA60-0YAO	带灯旋钮（短柄）头	2位, L-R, 90	白			37.2
3SB6061-2AB20-0YAO	带灯旋钮（短柄）头	2位, L<R, 90	红			48.1
3SB6061-2AB30-0YAO	带灯旋钮（短柄）头	2位, L<R, 90	黄			48.1
3SB6061-2AB40-0YAO	带灯旋钮（短柄）头	2位, L<R, 90	绿			48.1
3SB6061-2AB50-0YAO	带灯旋钮（短柄）头	2位, L<R, 90	蓝			48.1
3SB6061-2AB60-0YAO	带灯旋钮（短柄）头	2位, L<R, 90	白			48.1
3SB6061-2AL20-0YAO	带灯旋钮（短柄）头	3位, L-C-R, 2×60	红			40.5
3SB6061-2AL30-0YAO	带灯旋钮（短柄）头	3位, L-C-R, 2×60	黄			40.5
3SB6061-2AL40-0YAO	带灯旋钮（短柄）头	3位, L-C-R, 2×60	绿			40.5
3SB6061-2AL50-0YAO	带灯旋钮（短柄）头	3位, L-C-R, 2×60	蓝			40.5
3SB6061-2AL60-0YAO	带灯旋钮（短柄）头	3位, L-C-R, 2×60	白			40.5
3SB6061-2AM20-0YAO	带灯旋钮（短柄）头	3位, L>C<R, 2×60	红			51.4
3SB6061-2AM30-0YAO	带灯旋钮（短柄）头	3位, L>C<R, 2×60	黄			51.4
3SB6061-2AM40-0YAO	带灯旋钮（短柄）头	3位, L>C<R, 2×60	绿			51.4
3SB6061-2AM50-0YAO	带灯旋钮（短柄）头	3位, L>C<R, 2×60	蓝			51.4
3SB6061-2AM60-0YAO	带灯旋钮（短柄）头	3位, L>C<R, 2×60	白			51.4
3SB6061-2AN20-0YAO	带灯旋钮（短柄）头	3位, L-C<R, 2×60	红			51.4
3SB6061-2AN30-0YAO	带灯旋钮（短柄）头	3位, L-C<R, 2×60	黄			51.4
3SB6061-2AN40-0YAO	带灯旋钮（短柄）头	3位, L-C<R, 2×60	绿			51.4
3SB6061-2AN50-0YAO	带灯旋钮（短柄）头	3位, L-C<R, 2×60	蓝			51.4
3SB6061-2AN60-0YAO	带灯旋钮（短柄）头	3位, L-C<R, 2×60	白			51.4
3SB6061-2AP20-0YAO	带灯旋钮（短柄）头	3位, L>C-R, 2×60	红			51.4
3SB6061-2AP30-0YAO	带灯旋钮（短柄）头	3位, L>C-R, 2×60	黄			51.4
3SB6061-2AP40-0YAO	带灯旋钮（短柄）头	3位, L>C-R, 2×60	绿			51.4
3SB6061-2AP50-0YAO	带灯旋钮（短柄）头	3位, L>C-R, 2×60	蓝			51.4
3SB6061-2AP60-0YAO	带灯旋钮（短柄）头	3位, L>C-R, 2×60	白			51.4
3SB6061-2BA20-0YAO	带灯旋钮（长柄）头	2位, L-R, 90	红			41.6
3SB6061-2BA30-0YAO	带灯旋钮（长柄）头	2位, L-R, 90	黄			41.6
3SB6061-2BA40-0YAO	带灯旋钮（长柄）头	2位, L-R, 90	绿			41.6
3SB6061-2BA50-0YAO	带灯旋钮（长柄）头	2位, L-R, 90	蓝			41.6
3SB6061-2BA60-0YAO	带灯旋钮（长柄）头	2位, L-R, 90	白			41.6
3SB6061-2BB20-0YAO	带灯旋钮（长柄）头	2位, L<R, 90	红			52.5
3SB6061-2BB30-0YAO	带灯旋钮（长柄）头	2位, L<R, 90	黄			52.5
3SB6061-2BB40-0YAO	带灯旋钮（长柄）头	2位, L<R, 90	绿			52.5
3SB6061-2BB50-0YAO	带灯旋钮（长柄）头	2位, L<R, 90	蓝			52.5
3SB6061-2BB60-0YAO	带灯旋钮（长柄）头	2位, L<R, 90	白			52.5
3SB6061-2BL20-0YAO	带灯旋钮（长柄）头	3位, L-C-R, 2×60	红			44.8
3SB6061-2BL30-0YAO	带灯旋钮（长柄）头	3位, L-C-R, 2×60	黄			44.8
3SB6061-2BL40-0YAO	带灯旋钮（长柄）头	3位, L-C-R, 2×60	绿			44.8
3SB6061-2BL50-0YAO	带灯旋钮（长柄）头	3位, L-C-R, 2×60	蓝			44.8
3SB6061-2BL60-0YAO	带灯旋钮（长柄）头	3位, L-C-R, 2×60	白			44.8
3SB6061-2BM20-0YAO	带灯旋钮（长柄）头	3位, L>C<R, 2×60	红			55.8
3SB6061-2BM30-0YAO	带灯旋钮（长柄）头	3位, L>C<R, 2×60	黄			55.8

3SB6061-2BM40-0YAO	带灯旋钮（长柄）头	3位, L>C<R, 2×60	绿		55.8
3SB6061-2BM50-0YAO	带灯旋钮（长柄）头	3位, L>C<R, 2×60	蓝		55.8
3SB6061-2BM60-0YAO	带灯旋钮（长柄）头	3位, L>C<R, 2×60	白		55.8
3SB6061-2BN20-0YAO	带灯旋钮（长柄）头	3位, L-C<R, 2×60	红		55.8
3SB6061-2BN30-0YAO	带灯旋钮（长柄）头	3位, L-C<R, 2×60	黄		55.8
3SB6061-2BN40-0YAO	带灯旋钮（长柄）头	3位, L-C<R, 2×60	绿		55.8
3SB6061-2BN50-0YAO	带灯旋钮（长柄）头	3位, L-C<R, 2×60	蓝		55.8
3SB6061-2BN60-0YAO	带灯旋钮（长柄）头	3位, L-C<R, 2×60	白		55.8
3SB6061-2BP20-0YAO	带灯旋钮（长柄）头	3位, L>C-R, 2×60	红		55.8
3SB6061-2BP30-0YAO	带灯旋钮（长柄）头	3位, L>C-R, 2×60	黄		55.8
3SB6061-2BP40-0YAO	带灯旋钮（长柄）头	3位, L>C-R, 2×60	绿		55.8
3SB6061-2BP50-0YAO	带灯旋钮（长柄）头	3位, L>C-R, 2×60	蓝		55.8
3SB6061-2BP60-0YAO	带灯旋钮（长柄）头	3位, L>C-R, 2×60	白		55.8
3SB6060-4AA21-0YAO	钥匙开关头	2位, L-KR	黑		41.2
3SB6060-4AA01-0YAO	钥匙开关头	2位, KL-R	黑		41.2
3SB6060-4AA11-0YAO	钥匙开关头	2位, KL-KR	黑		41.2
3SB6060-4AB01-0YAO	钥匙开关头	2位, KL<R	黑		52.7
3SB6060-4AL01-0YAO	钥匙开关头	3位, L-KC-R	黑		41.2
3SB6060-4AL11-0YAO	钥匙开关头	3位, KL-KC-KR	黑		41.2
3SB6060-4AM01-0YAO	钥匙开关头	3位, L>KC<R	黑		52.7
3SB6060-4AP01-0YAO	钥匙开关头	3位, L>KC-R	黑		52.7
3SB6060-4AN01-0YAO	钥匙开关头	3位, L-KC<R	黑		52.7
3SB6060-4AP61-0YAO	钥匙开关头	3位, L>KC-KR	黑		52.7
3SB6060-4AN51-0YAO	钥匙开关头	3位, KL-KC<R	黑		52.7
3SB6060-1AA10-0YAO	蘑菇按钮头	30mm, 上拉解锁	黑		36.8
3SB6060-1AA20-0YAO	蘑菇按钮头	30mm, 上拉解锁	红		36.8
3SB6060-1AA30-0YAO	蘑菇按钮头	30mm, 上拉解锁	黄		36.8
3SB6060-1AA40-0YAO	蘑菇按钮头	30mm, 上拉解锁	绿		36.8
3SB6060-1AA50-0YAO	蘑菇按钮头	30mm, 上拉解锁	蓝		36.8
3SB6060-1AA60-0YAO	蘑菇按钮头	30mm, 上拉解锁	白		36.8
3SB6060-1BA10-0YAO	蘑菇按钮头	40mm, 上拉解锁	黑		36.8
3SB6060-1BA20-0YAO	蘑菇按钮头	40mm, 上拉解锁	红		36.8
3SB6060-1BA30-0YAO	蘑菇按钮头	40mm, 上拉解锁	黄		36.8
3SB6060-1BA40-0YAO	蘑菇按钮头	40mm, 上拉解锁	绿		36.8
3SB6060-1BA50-0YAO	蘑菇按钮头	40mm, 上拉解锁	蓝		36.8
3SB6060-1BA60-0YAO	蘑菇按钮头	40mm, 上拉解锁	白		36.8
3SB6060-1CA10-0YAO	蘑菇按钮头	60mm, 上拉解锁	黑		36.8
3SB6060-1CA20-0YAO	蘑菇按钮头	60mm, 上拉解锁	红		36.8
3SB6060-1CA30-0YAO	蘑菇按钮头	60mm, 上拉解锁	黄		36.8
3SB6060-1CA40-0YAO	蘑菇按钮头	60mm, 上拉解锁	绿		36.8
3SB6060-1CA50-0YAO	蘑菇按钮头	60mm, 上拉解锁	蓝		36.8
3SB6060-1CA60-0YAO	蘑菇按钮头	60mm, 上拉解锁	白		36.8
3SB6060-1AC10-0YAO	蘑菇按钮头	30mm, 瞬动	黑		35.2
3SB6060-1AC20-0YAO	蘑菇按钮头	30mm, 瞬动	红		35.2
3SB6060-1AC30-0YAO	蘑菇按钮头	30mm, 瞬动	黄		35.2
3SB6060-1AC40-0YAO	蘑菇按钮头	30mm, 瞬动	绿		35.2
3SB6060-1AC50-0YAO	蘑菇按钮头	30mm, 瞬动	蓝		35.2

3SB6060-1AC60-0YAO	蘑菇按钮头	30mm, 瞬动	白			35.2
3SB6060-1BC10-0YAO	蘑菇按钮头	40mm, 瞬动	黑			35.2
3SB6060-1BC20-0YAO	蘑菇按钮头	40mm, 瞬动	红			35.2
3SB6060-1BC30-0YAO	蘑菇按钮头	40mm, 瞬动	黄			35.2
3SB6060-1BC40-0YAO	蘑菇按钮头	40mm, 瞬动	绿			35.2
3SB6060-1BC50-0YAO	蘑菇按钮头	40mm, 瞬动	蓝			35.2
3SB6060-1BC60-0YAO	蘑菇按钮头	40mm, 瞬动	白			35.2
3SB6060-1CC10-0YAO	蘑菇按钮头	60mm, 瞬动	黑			35.2
3SB6060-1CC20-0YAO	蘑菇按钮头	60mm, 瞬动	红			35.2
3SB6060-1CC30-0YAO	蘑菇按钮头	60mm, 瞬动	黄			35.2
3SB6060-1CC40-0YAO	蘑菇按钮头	60mm, 瞬动	绿			35.2
3SB6060-1CC50-0YAO	蘑菇按钮头	60mm, 瞬动	蓝			35.2
3SB6060-1CC60-0YAO	蘑菇按钮头	60mm, 瞬动	白			35.2
3SB6061-1AC20-0YAO	带灯蘑菇按钮头	30mm, 瞬动	红			44.2
3SB6061-1AC30-0YAO	带灯蘑菇按钮头	30mm, 瞬动	黄			44.2
3SB6061-1AC40-0YAO	带灯蘑菇按钮头	30mm, 瞬动	绿			44.2
3SB6061-1AC50-0YAO	带灯蘑菇按钮头	30mm, 瞬动	蓝			44.2
3SB6061-1AC60-0YAO	带灯蘑菇按钮头	30mm, 瞬动	白			44.2
3SB6061-1BC20-0YAO	带灯蘑菇按钮头	40mm, 瞬动	红			44.2
3SB6061-1BC30-0YAO	带灯蘑菇按钮头	40mm, 瞬动	黄			44.2
3SB6061-1BC40-0YAO	带灯蘑菇按钮头	40mm, 瞬动	绿			44.2
3SB6061-1BC50-0YAO	带灯蘑菇按钮头	40mm, 瞬动	蓝			44.2
3SB6061-1BC60-0YAO	带灯蘑菇按钮头	40mm, 瞬动	白			44.2
3SB6061-1CC20-0YAO	带灯蘑菇按钮头	60mm, 瞬动	红			44.2
3SB6061-1CC30-0YAO	带灯蘑菇按钮头	60mm, 瞬动	黄			44.2
3SB6061-1CC40-0YAO	带灯蘑菇按钮头	60mm, 瞬动	绿			44.2
3SB6061-1CC50-0YAO	带灯蘑菇按钮头	60mm, 瞬动	蓝			44.2
3SB6061-1CC60-0YAO	带灯蘑菇按钮头	60mm, 瞬动	白			44.2
3SB6060-1HB20-0YAO	急停按钮头	40mm, 旋转解锁	红			40.9
3SB6060-1HA20-0YAO	急停按钮头	40mm, 上拉解锁	红			37.5
3SB6060-1HD20-0YAO	急停按钮头	40mm, 钥匙解锁	红			58.3
3SB6400-1AA10-1BA0	触点	1NO				10.4
3SB6400-1AA10-1CA0	触点	1NC				10.4
3SB6401-1BA20-1AA0	灯座	6V AC/DC	红			16.4
3SB6401-1BA30-1AA0	灯座	6V AC/DC	黄			16.4
3SB6401-1BA40-1AA0	灯座	6V AC/DC	绿			16.4
3SB6401-1BA50-1AA0	灯座	6V AC/DC	蓝			16.4
3SB6401-1BA60-1AA0	灯座	6V AC/DC	白			16.4
3SB6402-1BA20-1AA0	灯座	12V AC/DC	红			16.4
3SB6402-1BA30-1AA0	灯座	12V AC/DC	黄			16.4
3SB6402-1BA40-1AA0	灯座	12V AC/DC	绿			16.4
3SB6402-1BA50-1AA0	灯座	12V AC/DC	蓝			16.4
3SB6402-1BA60-1AA0	灯座	12V AC/DC	白			16.4
3SB6403-1BA20-1AA0	灯座	24V AC/DC	红			16.4
3SB6403-1BA30-1AA0	灯座	24V AC/DC	黄			16.4
3SB6403-1BA40-1AA0	灯座	24V AC/DC	绿			16.4
3SB6403-1BA50-1AA0	灯座	24V AC/DC	蓝			16.4

3SB6403-1BA60-1AA0	灯座	24V AC/DC	白			16.4
3SB6404-1BA20-1AA0	灯座	48V AC/DC	红			16.4
3SB6404-1BA30-1AA0	灯座	48V AC/DC	黄			16.4
3SB6404-1BA40-1AA0	灯座	48V AC/DC	绿			16.4
3SB6404-1BA50-1AA0	灯座	48V AC/DC	蓝			16.4
3SB6404-1BA60-1AA0	灯座	48V AC/DC	白			16.4
3SB6405-1BA20-1AA0	灯座	110V AC/DC	红			16.4
3SB6405-1BA30-1AA0	灯座	110V AC/DC	黄			16.4
3SB6405-1BA40-1AA0	灯座	110V AC/DC	绿			16.4
3SB6405-1BA50-1AA0	灯座	110V AC/DC	蓝			16.4
3SB6405-1BA60-1AA0	灯座	110V AC/DC	白			16.4
3SB6406-1BA20-1AA0	灯座	220V AC	红			16.4
3SB6406-1BA30-1AA0	灯座	220V AC	黄			16.4
3SB6406-1BA40-1AA0	灯座	220V AC	绿			16.4
3SB6406-1BA50-1AA0	灯座	220V AC	蓝			16.4
3SB6406-1BA60-1AA0	灯座	220V AC	白			16.4
3SB6407-1BA20-1AA0	灯座	220V DC	红			16.4
3SB6407-1BA30-1AA0	灯座	220V DC	黄			16.4
3SB6407-1BA40-1AA0	灯座	220V DC	绿			16.4
3SB6407-1BA50-1AA0	灯座	220V DC	蓝			16.4
3SB6407-1BA60-1AA0	灯座	220V DC	白			16.4
3SB6408-1BA20-1AA0	灯座	380V AC	红			18.1
3SB6408-1BA30-1AA0	灯座	380V AC	黄			18.1
3SB6408-1BA40-1AA0	灯座	380V AC	绿			18.1
3SB6408-1BA50-1AA0	灯座	380V AC	蓝			18.1
3SB6408-1BA60-1AA0	灯座	380V AC	白			18.1
3SB6901-0GH20	红色灯罩	附件	红			1.6
3SB6901-0GH30	黄色灯罩	附件	黄			1.6
3SB6901-0GH40	绿色灯罩	附件	绿			1.6
3SB6901-0GH50	蓝色灯罩	附件	蓝			1.6
3SB6901-0GH60	白色灯罩	附件	白			1.6
3SB6900-0AB	空白符号片	附件				1.6
3SB6900-0JS	插入式符号片-分闸	附件				1.6
3SB6900-0JT	插入式符号片-合闸	附件				1.6
3SB6900-0JU	插入式符号片-启动	附件				1.6
3SB6900-0JV	插入式符号片-停止	附件				1.6
3SB6900-0JW	插入式符号片-打开	附件				1.6
3SB6900-0JX	插入式符号片-关闭	附件				1.6
3SB6900-0JY	插入式符号片-上升	附件				1.6
3SB6900-0KA	插入式符号片-下降	附件				1.6
3SB6900-0KB	插入式符号片-故障	附件				1.6
3SB6900-0KC	插入式符号片-试验	附件				1.6
3SB6900-0KD	插入式符号片-电源	附件				1.6
3SB6900-0KE	插入式符号片-开	附件				1.6
3SB6900-0KF	插入式符号片-关	附件				1.6
3SB6900-0JA	插入式符号片-START	附件				1.6
3SB6900-0JB	插入式符号片-STOP	附件				1.6



3SB6900-0JC	插入式符号片-ON	附件				1.6
3SB6900-0JD	插入式符号片-OFF	附件				1.6
3SB6900-0JE	插入式符号片-UP	附件				1.6
3SB6900-0JF	插入式符号片-DOWN	附件				1.6
3SB6900-0JG	插入式符号片-OPEN	附件				1.6
3SB6900-0JH	插入式符号片-CLOSE	附件				1.6
3SB6900-0JJ	插入式符号片-RESET	附件				1.6
3SB6900-0JK	插入式符号片-AUTO	附件				1.6
3SB6900-0JL	插入式符号片-○	附件				1.6
3SB6900-0JM	插入式符号片-I	附件				1.6
3SB6900-0JN	插入式符号片-II	附件				1.6
3SB6900-0JP	插入式符号片-→	附件				1.6
3SB6900-0JQ	插入式符号片-	附件				1.6
3SB6900-0JR	插入式符号片-○	附件				1.6
3SB6900-0GC	急停警告圈, 60mm, 印有“EMERGENCY STOP”字样					2.9
3SB6900-0GF	急停警告圈, 90mm, 印有“EMERGENCY STOP”字样					3.2
3SB6900-0HA	铭文框: 铭文书写尺寸: 25*10mm					1.9
3SB6900-0HB	铭文框: 铭文书写尺寸: 25*18mm					2.6